

Sky solar sensor

solar lighting

5572, 5573

8W



BENEITO FAURE®

passion for led light

English *To read the Operating modes instructions in another language, visit the product page on our website.


Modos de funcionamiento/ Modes de fonctionnement/ **Operating modes**/ Modes de fonctionnement/ Funktionsarten/ Modalità di funzionamento

Operating modes

1. Mode 1:
 - o **Stand-by status:** 10%
 - o **Action:** All lights turn on after a person arrives.
 - o **After the person leaves:** 30 seconds after the person leaves, the lights return to 10%.
2. Mode 2:
 - o **Stand-by status:** 0%
 - o **Action:** 100% illumination when a person arrives.
 - o **After the exit of the person:** The lights turn off 30 seconds after the person leaves.
3. Mode 3:
 - o **Standby state:** 10% always on.
4. Mode 4:
 - o **Action:** Switched off.

Download Time

1. Mode 1:
 - o **Number of times downloaded:** 300 times
2. Mode 2:
 - o **Number of times downloaded:** 400 times
3. **Constant light:** 12 hours



Replaceable battery



RoHS



**3 YEARS
WARRANTY**
BATTERY 2 YEARS

**30.000
HOURS**

**9
HOURS**

**10% 100%
12H. 2H.**

**4.000
mAh**

**IP
54**

**CRI
≥80**



120°



4-6m

**PIR
SENSOR**

ON OFF

**+45°C
-20°C**

Sky solar sensor

solar

5572, 5573




8W



BENEITO FAURE®



passion for led light

Instrucciones de montaje/ Assembly instructions/ Instructions de montage/ Montageanleitung/ Istruzioni di montaggio





1.0

2.0



3.0

4.0



5.0



RoHS



CRI
≥80



3
YEARS
WARRANTY



54
IP



50.000
HOURS